Nightingale — Disassembly Instructions for 1301/1302/1303 Lakeshore

**Items are listed in suggested order of disassembly – Estimated time required – 90 minutes

STEP	DESCRIPTION	QTY	MATERIAL(S)	♻	TOOL	PROCEDURE
1	Frame Bolts	12	Steel	Y	A	Remove bolts holding steel frame onto sofa using screwdriver
2	Liner	1	Fabric	Y	E,F	Remove the liner on the bottom of the sofa with knife and pliers
3	Arm Bolts and Washers	8	Steel	Y	B	Access and remove the 8 Arm Bolts through the now exposed underside of the seat component using a wrench or socket set.
4	Arm	2	Plywood, OSB and Hardwood and steel*	Y	E, F	Cut upholstery from arms using knife and remove staples using pliers
5	Arm Foam	5	Polyurethane Foam	Y	E	Cut or steam seat foam from plywood arm frame on all sides
6	Seat	1	Plywood	Y	E, F	Cut upholstery from seat frame using knife and remove staples using pliers
7	Seat Foam	2	Polyurethane Foam	Y	E	Cut or steam seat foam from seat frame
8	Webbing	6	Fabric	Y	E, F	Removes staples holding webbing on to frame wit pliers
9	Back	1	Plywood	Y	E, F	Cut upholstery from back frame using knife and remove staples using pliers
10	Back Foam	3	Polyurethane Foam	Y	E	Cut or steam back foam from back frame
11	Frame Plugs	4	Plastic (PE) ⚠ (7)	Y	A	Pry plugs out of bottom of frame with screwdriver

* part is comprised of co-mingled materials. Contact your recycling facility

A. Screwdriver | B. Wrench | C. Allen Key | D. Hammer | E. Knife | F. Pliers